

ZEITGEIST

TD-50X	Type	Sensitivity	Threshold	Curve	Scan Time	Retrig Canc.	Mask Time	xTalk	Rim Gain	Head/Rim Adj.
CAD Becken										
14" HiHat	VH-13	9	5	Linear	2	1	8	0	0,9	-
10" Splash	RT-30K	5,5	15	EXP1	3,6	16	12	-	-	-
12" Splash	RT-30K	5,5	15	EXP1	3,6	16	12	-	-	-
14" Crash	CY-14C-T	7	2	EXP1	2,4	9	10	-	1	-
16" Crash/China	CY-14C-T	7	2	EXP1	2,4	9	10	-	1	-
18" Crash/China	CY-16R-T	7	2	EXP1	2,4	9	10	-	1	-
18" Ride	CY-16R-T	9	2	Linear	2,5	5	10	15	1,1	-
20" Ride	CY-16R-T	9	2	Linear	2,5	5	10	15	1,1	-
ECP Becken										
9" Splash	CY-5	6	2	Linear	2	5	10	30	1	-
11" Splash	CY-8	6	2	Linear	2	5	10	30	0,8	-
12" HiHat	VH-10	6	6	Linear	2,8	1	8	15	0,9	-
HiHat	VH-10	6	6	Linear	2,8	1	8	15	0,9	-
13" Crash	CY-12C-T	5,5	2	Linear	2,4	7	10	30	0,7	-
13" Ride	CY-14R-T	4	2	Linear	2,4	5	10	30	1	-
15" China	CY-14C-T	6	2	Linear	2,4	7	10	30	0,7	-
15" Ride	CY-16R-T	4	2	Linear	2,4	5	10	30	1,2	-
18" Ride	CY-16R-T	4	2	Linear	2,4	5	10	30	1,2	-
20" Ride	CY-16R-T	4	2	Linear	2,4	5	10	30	1,2	-
Pads										
20" Kick	KD-120	8	5	Exp2	2,8	10	10	-	-	-
13" Snare	PD-128	3	2	Log1	2,8	3	9	-	1,7	20
10" Tom	PDX-12	5	2	Linear	2	3	9	-	1,9	20
12" Tom	PDX-12	5	2	Linear	2	3	9	-	1,9	20
13" Floor Tom	PDX-12	5	2	Linear	2	3	9	-	1,9	20